

# Roppe Metal Stair Treads



## Product Data

Section 9

Resilient Flooring



## Maintenance

DO NOT perform any maintenance or expose the product to water, rain, cleaning or cleaning solutions/chemicals or other materials for at least 72 hours after installation to allow the adhesive to properly cure. Immediately remove any adhesive residue from the materials surface to prevent permanent discoloration. Remove any covering that may have been used to protect the material. The Metal Stair Treads, Metal Stair Nosings and Metal Flat Step must be properly installed with all mechanical fasteners and adhered completely with adhesive and cleaned before released for normal use. Sweep to remove dirt and other particulate. ROPPE Metal Stair Treads, Metal Stair Nosings and Metal Flat Step should be cleaned periodically to maximize the life and appearance of the material. If left un-cleaned, sand, grit, and grime buildup on the surface can become very abrasive reducing the life and appearance of the product. Metal Stair Treads, Metal Stair Nosings and Metal Flat Step can be cleaned using a general purpose industrial floor cleaner. First check for compatibility by testing cleaning products to assure damage does not occur on the materials colored face or aluminum. For encrusted dirt use a stiff bristled brush with an industrial cleaner to remove. Material can also be cleaned with a pressure washer not exceeding 1,000 psi. Pressure washing above 1,000 psi will damage the material and epoxy filled face. Interior treads may be swept, vacuumed and spot cleaned. A neutral pH cleaning solution or a mild soap and water solution may be used for shampooing. DO NOT use highly alkaline cleaners, highly acidic cleaners, or sweeping compounds containing oils or solvents. DO NOT allow cleaning solutions or other chemicals that could deteriorate the adhesive to stand on the flooring. Spills must be immediately removed from the flooring. Exterior installations can be simply hosed off and left to dry. Chewing gum can be removed by using Mellow Craft aerosol Chewing Gum Remover. Scuff marks can be removed from aluminum nose by scrubbing with a green Scotch-Brite Pad in the direction of the treads length.

6-10

